

"No Footings"

Instructions for installing tile in a home without footings:

1. Break trenches approx. 16" wide.
2. Dig trenches approx. 12" deep from top of floor & "form" footing under block at 45 degree angle.
3. Line trench with Filter Fabric (approx. 20" wide) anchoring to bottom of block.
4. Install 12" wide piece of drain board over Filter Fabric, using extra Fabric on drain board to overlap trench filter.
5. Install tile & rock as diagrammed.
6. Cover rock with poly.
7. Replace concrete with same thickness as original

